

Multifunction Steering Wheel , (1XT),(1XX),(1XW),(2PF),(2PK),(2ZM),(2ZQ),(2ZS) From January 2011




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Wiring Diagram







## Steering Column Electronics Control Module, Instrument Cluster CAN Bus High Wire Junction 2

- J285 Instrument Cluster Control Module
- J527 Steering Column Electronics Control Module
- T16e 16-Pin Connector
- T17o 17-Pin Connector, In the Connector Station, Right A-Pillar
- T32 32-Pin Connector
- T46b 46-Pin Connector
- TV81 Instrument Cluster CAN Bus High Wire Junction 2
- TV84 Instrument Cluster CAN Bus Low Wire Junction 2
- A204 Instrument Cluster CAN Bus High Connection (in Instrument Panel Wiring Harness)
- A205 Instrument Cluster CAN Bus Low Connection (in Instrument Panel Wiring Harness)
- B708 Instrument Cluster CAN Bus High Connection 1 (in Main Wiring Harness)
- B709 Instrument Cluster CAN Bus Low Connection 1 (in Main Wiring Harness)
  - Data Bus Wire (CAN Bus)

= white

= black = red = red

= brown = green

= blue = grey

= lilac = lilac = yellow

= orange

= pink

or

rs

4G2-020030620

= white = black

= red

= red

= brown

= green = blue = grey = lilac = lilac = yellow


= orange

= pink

or

rs





# Steering Column Electronics Control Module, Powertrain CAN Bus High Wire Junction 2

J527 Steering Column Electronics Control Module
J533 Data Bus on Board Diagnostic Interface
T16e 16-Pin Connector
T17i 17-Pin Connector, In the Left A-Pillar Connector Station
T32b 32-Pin Connector
T46a 46-Pin Connector
T46b 46-Pin Connector
TV33 Powertrain CAN Bus High Wire Junction
TV37 Powertrain CAN Bus Low Wire Junction
TV79 Powertrain CAN Bus High Wire Junction 2
TV82 Powertrain CAN Bus Low Wire Junction 2
Powertrain CAN Bus High Connection 1 (in Main Wiring Harness)

Powertrain CAN Bus Low Connection 1 (in Main Wiring Harness)


\* Data Bus Wire (CAN Bus)

#### Signal Horn Activation, Steering Column Electronics Control Module

- F350 Spiral Spring H
- Signal Horn Activation J453 Multifunction Steering Wheel Control Module
- Steering Column Electronics Control Module
- Driver Airbag Igniter
- Driver Airbag Igniter 2
- T1iy 1-Pin Connector
- T1iz 1-Pin Connector
- T1ja 1-Pin Connector
- T2fk 2-Pin Connector
- T4ah 4-Pin Connector
- T4ahx 4-Pin Connector
- T4hc 4-Pin Connector
- T12v 12-Pin Connector
- T4 4-Pin Connector
- Heated Steering Wheel
- Ground Connection 1 (in Steering Wheel Wiring Harness)
  - For Vehicles with Heated Steering Wheel
- Adapter Cable

= black

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




### Steering Column Electronics Control Module

- E440 Left Multifunction Buttons on Steering Wheel E441 Right Multifunction Buttons on Steering Wheel
- E479 Tiptronic Upshift Button
- E480 Tiptronic Downshift Button E522 Steering Wheel Heating Button
- J453 Multifunction Steering Wheel Control Module
- J527 Steering Column Electronics Control Module
- T3di 3-Pin Connector
- T3dj 3-Pin Connector
- T3dk 3-Pin Connector
- T3dl 3-Pin Connector
- T9e 9-Pin Connector
- Γ9f 9-Pin Connector
- Adapter Cable



J527



= white = black = red = red = brown br = green = blue = grey = lilac = lilac = yellow = orange or rs = pink

4G2-020060620



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

4G2-020070620

rs

= pink

### Lane Assistance Button, Steering Column Electronics Control Module

E517 Lane Assistance Button

G428 Heated Steering Wheel Sensor

J234 Airbag Control Module

J453 Multifunction Steering Wheel Control Module


J527 Steering Column Electronics Control Module

T4ah 4-Pin Connector

T17p 17-Pin Connector, In the Connector Station, Right A-Pillar

T100 100-Pin Connector

For Vehicles with Lane Assistance





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

ws	=	white	
SW	=	black	
ro	=	red	
rt	=	red	
br	=	brown	
gn	=	green	
bl	=	blue	
gr	=	grey	
li	=	lilac	
vi	=	lilac	
ge	=	yellow	
or	=	orange	